RS82H

HERITAGE TRACTOR

CODE 148A

SPARE PARTS MANUAL


English Version
FROM SERIAL NO: 148A001001
Issue: 04.07.02

MANUAL PART NO: 148003 (REV.0.)

When ordering spare parts please give the following information.


PART NUMBER, DESCRIPTION AND QUANTITY REQUIRED,
MACHINE TYPE, MODEL AND SERIAL NUMBER.

Use only Hayter spare parts, others may be dangerous and will invalidate the machine warranty.


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
51
52
53
54
55
56
1CRS8202A


1.5 STEERING & FRONT AXLE 1.5

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Steering Wheel	AL514013	1	
2	Roll Pin	AL700664	1	
3	Washer	AL521115	1	
4	Bush Flanged	AL514197	2	
5	Cover	AL514085	1	
6	Bolt	AL700553	6	
7	Nut	AL321126	1	
8	Hood Lock Down	AL514416	1	
9	Bolt	AL700555	1	
10	Washer	AL700200	1	
11	Clip	AL702724	4	
12	Washer	AL700719	1	
13	Shim	AL701166	1	
14	Nut	AL700276	6	
15	Washer	AL700148	6	
16	Steering Rod	AL514032	1	
17	Support Rod	AL514049	1	
18	Bolt	AL703191	4	
19	Key	AL704275	1	
20	Washer	AL701765	4	
21	Nut	AL700121	5	
22	Steering Gear	AL514009	1	
23	Spacer	AL51438730	1	
24	C Clip	AL702893	1	
25	Washer	AL702574	1	
26	Washer	AL700140	1	
27	Spacer	AL514145	1	
28	Quadrant Assembly	AL51468830	1	
29	Washer	AL521123	1	
30	Bolt	AL702381	1	
31	Bolt	AL701470	1	
32	Washer	AL700139	1	
33	Pin	AL700209	1	
34	Clevis	AL700739	1	
35	Nut	AL700109	4	
36	Rod	AL51468530	1	
37	Ball Joint	AL514701	3	
38	Bracket	AL51477630	1	
39	Nut	AL348988	1	
40	Bolt	AL523134	1	
41	Nut	AL700122	4	
42	Washer	AL701083	2	
43	Bushing	AL51436030	1	
44	Bush Flanged	AL514042	4	
45	Axle	AL521075	1	
46	Nipple-Grease	AL700203	1	
47	LH Axle	AL521170	1	
48	Bearing	AL521268	2	
49	Wheel Assembly	AL52104640	2	
50	Inner Tube	AL546220	2	Not Illustrated
51	Rod	AL51404130	1	
52	RH Axle	AL521171	1	
53	Bolt	AL701985	1	
54	Bolt	AL702812	1	
55	Bolt	AL701489	2	
56	Chassis	AL51405101	1	



1CRS8207A

1.7	ENGINE COVER AND PANELS	1.7


ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Decal Grass Blade	410064	1	
2	Panel	AL52157813	1	
3	Screw	AL521679	2	
4	Lens Assembly	AL521720	1	
5	Grille	AL52157413	1	
6	Screw	AL514317	3	
7	Nut	AL514331	7	
8	Screw	AL704350	7	
9	Receptacle fastener	AL521676	6	
10	Screw	AL702572	6	
11	Strut	AL521460	1	
12	Decal RH	149007	1	
13	Panel RH	AL52157513	1	
14	Hood Assembly	AL52157213	1	
15	Screw	AL510177	2	
16	Washer	AL700148	6	
17	Rod	AL514419	1	
18	Cover	AL521084	1	
19	Screw	AL518482	2	
20	Screw	AL514316	6	
21	Washer	AL703005	11	
22	Screw	AL704325	6	
23	Cover	AL51400213	1	
24	Nut	AL700276	6	
25	Mat RH	AL51416101	1	
26	Decal LH	149006	1	
27	Panel LH	AL52157613	1	
28	Mat LH	AL51496401	1	
29	Screw	AL514544	4	
30	Cover RH	AL521085	1	
31	Deck seat	AL52142513	1	
32	Deck	AL51400413	1	
33	Cover LH	AL521164	1	
34	RH Front Bracket	AL521461	1	
35	LH Front Bracket	AL521462	1	
36	Bolt	AL700799	4	
37	Nut	AL321126	4	
38	Washer	AL700147	6	
39	Screw	AL348947	2	
40	Plug	AL51499901	1	
41	Plug	AL52113801	1	
42	Decal - Caution	AL526506	1	
43	Decal Parking Brake	AL	1	



ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Belt Cutter	AL514083	1	
2	Clip	AL543474	4	
3	Bolt	AL52118130	3	
4	Latch	AL52114730	4	
5	Pin	AL52114830	1	
6	Spring	AL521202	1	
7	Square Link	AL52114930	1	
8	Washer	AL700138	4	
9	Pulley	AL514098	1	
10	Washer	AL700141	1	
11	Nut	AL700232	1	
12	Nut	AL700121	4	
13	Washer	AL700148	1	
14	Pulley	AL514716	1	
15	Screw	AL701168	2	
16	Packer	AL514434	1	
17	Bracket	AL51440230	1	
18	Cir - Clip	AL700413	1	
19	Washer	AL700139	2	
20	Nut	AL700119	2	
21	Spacer	AL51421630	1	
22	Bracket	AL51439430	1	
23	Bracket	AL51440530	1	
24	Bolt	AL701672	1	
25	Bush	AL514220	2	
26	Direction Rod	AL52138330	1	
27	Washer	AL700137	6	
28	Chute	AL521089	1	
29	Screw	AL348947	7	
30	Spring	AL514439	1	
31	Screw	AL700702	3	
32	Height Adjust	AL521129	1	
33	Washer	AL701647	1	
34	Latch Lever	AL52119030	2	
35	Nut	AL700276	7	
36	Bar	AL51425330	2	
37	Pin	AL701626	2	
38	Clip - Hitch Pin	AL51420801	1	
39	Bolt	AL700704	8	
40	Rear Adjuster Spacer	AL51415930	2	
41	Bearings	AL700503	1	
42	Bolt	AL523134	2	
43	Pin	AL51412830	1	
44	Spring	AL514437	1	
45	Quill	AL514258	1	
46	Bracket	AL52138230	1	
47	Washer - Star	AL	1	
48	Deck	AL51420401	1	
49	Ring	AL522575	1	
50	Connector	AL321347	1	




ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
51	Screw	AL521281	3	
52	Screw Hexagon	AL701127	1	
53	Washer	AL701765	1	
54	Connector	AL321347	1	
55	Spacer	AL514094	1	
56	Bearing	AL700503	1	
57	Deck Bush	AL521695	1	
58	Shaft	AL514092	1	
59	Key	AL701595	4	
60	Blade	AL514658	1	
61	Blade Fixing - Kit	AL514659	1	
62	Washer	AL702254	2	
63	Screw	AL701336	1	
64	Blade - Holder	AL514176	1	
65	Front Height Adjuster	AL51421101	1	
66	Height Adjuster	AL51421301	2	
67	Nut	AL700122	6	
68	Washer	AL700151	8	
69	Decal - Hands & Feet	AL526507	2	


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20


1.13 GRASSBAG ASSEMBLY 1.13

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Handle - Grip	AL514079	1	
2	Lever	AL51407830	1	
3	Screw Hexagon	AL703363	9	
4	Washer	AL703005	9	
5	Handle	AL514655	1	
6	Cover	AL514006	1	
7	Bolt	AL514802	2	
8	Washer	AL700148	2	
9	Latch	AL521038	1	
10	Screw	AL348954	2	
11	Pin	AL700166	1	
12	Frame - Upper Grass Collector	AL52129201	1	
13	Washer	AL700137	13	
14	Nut	AL700276	11	
15	Screw	AL510433	1	
16	Frame - Lower Grass Collector	AL514182	1	
17	Bar	AL51424330	1	
18	Bar	AL514183	1	
19	Grassbag Fabric	AL514080	1	
20	Screw	AL703563	2	




1.15 REAR AXLE AND CONTROL PEDALS 1.15

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Spring	AL514386	1	
2	Star Washer	AL510566	2	
3	Pin - Pedal	AL51442430	2	
4	Bolt	AL514316	2	
5	Pedal	AL51406701	1	
6	Pedal Arm	AL51406830	1	
7	Bolt	AL700555	3	
8	Clip	AL514396	2	
9	Switch	AL514327	2	
10	Rivet	AL701395	4	
11	Switch Halter	AL514385	2	
12	Aduster Cover - Black	AL302231	1	
13	Arm - RH	AL514410	1	
14	Nut	AL700276	1	
15	Cable	AL514157	1	
16	Nut	AL700121	14	
17	Ball Joint	AL514239	2	
18	Rod	AL514768	1	
19	Screw	AL701006	3	
20	Bracket - Cable	AL51418130	1	
21	Nut	AL700246	1	
22	Nut	AL700108	2	
23	Bracket	AL51424130	1	
24	Bolt	AL703892	1	
25	Washer	AL701765	1	
26	Control Lever Drive	AL51413130	1	
27	Bushing - Sliding	AL514446	1	
28	Bushing	AL514240	1	
29	Bracket - Pivot	AL51475730	1	
30	Knob	AL514174	1	
31	Lever	AL51482230	1	
32	Bracket Lever	AL51477430	1	
33	Bolt	AL704270	1	
34	Washer	AL700656	1	
35	Spacer	AL51423730	1	
36	C-Clip	AL702724	2	
37	Washer	AL700719	2	
38	Washer	AL704263	4	
39	Rear Wheel Assembly	AL51401540	2	
40	Inner Tube	AL546222	2	Not Shown
41	Spacer	AL51476730	1	
42	Key - Drive Shaft	AL514313	2	
43	Screw	AL701612	1	
44	Washer	AL700200	1	
45	Spring	AL514605	1	
46	Bolt	AL700303	4	
47	Hydro Gearbox	AL514728	1	
48	Gear Shift Lever	AL51444830	1	
49	Washer	AL700148	1	
50	Screw	AL511461	1	




ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
51	Washer	AL700138	1	
52	Spacer	AL51866030	1	
53	Bolt	AL701704	6	
54	Bolt	AL701006	2	
55	Washer	AL704272	2	
56	Bearing Assembly	AL514081	1	
57	Pulley	AL514075	1	
58	Spring LH	AL514295	1	
59	Pedal Arm Left	AL52118530	1	
60	Pedal Left	AL51416801	1	
61	Pedal Stop	AL521168	1	
62	Screw	AL5827377	2	
63	Lock Fix	AL52118630	1	
64	Lock Pivot	AL52118730	1	
65	Clutch Cable	AL514070	1	


1CRS8202A
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22


GRASSBAG MOUNTING

1.19

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Nut - Lock	AL700121	13	
2		AL514689	1	
3	Bolt	AL700967	2	
4	Bolt	AL701672	1	
5	Bracket	AL51475201	1	
6	Screw	AL701006	3	
7	Screw	AL701011	1	
8	Back Plate	AL51483801	1	
9	Washer	AL700147	2	
10	Washer	AL700150	7	
11	Switch	AL514329	1	
12	Grip Fix	AL526521	2	
13	Audible Switch Assembly	AL521339	1	Includes item 11,12,14
14	Lever Plastic	AL514682	1	
15	Screw	AL511693	2	
16	Screw	AL701375	8	
17	Nut	AL700276	8	
18	Bolt	AL703892	6	
19	Bracket - RH	AL51418501	1	
20	Bracket - LH	AL54118601	1	
21	Roll Pin	AL700661	1	
22	Rivet	AL358710	2	



1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
42
43

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Strip - Rubber	AL514818	1	
2	Battery	AL512073	1	
3	Screw 5 x 16	AL700974	2	
4	Washer	AL701650	2	
5	Nut	AL701366	2	
6	Clip	AL512101	1	
7	Clip	AL512100	1	
8	Tray	AL514670	1	
9	Fuel Cap	AL544600	1	
10	Fuel Tank	AL514839	1	
11	Fuel Pipe	AL51437910	1	
12	Nut	AL348988	4	
13	Washer	AL701765	2	
14	Belt Guide	AL514398	1	
15	Bolt	AL700573	2	
16	Belt Guide	AL514347	1	
17	Belt Guide	AL514399	1	
18	Nut	AL700276	2	
19	Belt Guide	AL514620	1	
20	Spring	AL522087	1	
21	Belt	AL514882	1	
22	Pulley	AL514717	1	
23	Washer	AL700148	2	
24	Bolts	AL523134	2	
25	Spacer	AL51480430	1	
26	Washer	AL700656	1	
27	Bolt	AL701171	1	
28	Pulley	AL514716	1	
29	Washer	AL70108310	1	
30	Tensioning Roll	AL52109630	1	
31	Screw	AL700551	3	
32	Pulley	AL514322	1	
33	Clutch Cable	AL514070	1	
34	Washer	AL704266	1	
35	Bolt	AL522515	1	
36	Belt Guide Starter	AL51438830	1	
37	Screw	AL701006	3	
38	Washer	AL700150	3	
39	Clip	AL544515	2	
40	Briggs & Stratton		1	Contact Dealer
41	Battery Charger	AL117354	1	Not Shown
42	Nut - Lock	AL700121	7	
43	Key	AL514326	1	


1CRS8206A
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31

1.23 SEAT ASSEMBLY 1.23

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Seat	AL514167	1	
2	Seat Plate	AL514611	1	
3	Screw	AL700051	4	
4	Washer	AL701765	4	
5	Bolt	AL518560	1	
6	Star Washer	AL510566	2	
7	Articulated Rod	AL51414130	1	
8	Base - Seat	AL514612	1	
9	Cap Cover	AL514346	2	
10	Screw	AL701006	2	
11	Seat Switch	AL514327	1	
12	Washer	AL700150	2	
13	Spring	AL514307	2	
14	Cable	AL514157	1	
15	Gear Segment	AL625877	1	
16	Lever	AL514224	1	
17	Washer	AL700151	1	
18	Bolt	AL704264	1	
19	Washer - Star	AL504729	1	
20	Spring	AL2045480006	1	
21	Button	AL2042850001	1	
22	Grip Handle	AL375725	1	
23	Nut	AL700121	4	
24	Bolt	AL700545	4	
25	Heat - Deflector	AL521475	1	
26	Plug	AL504516	2	
27	Bar - Front	AL52173101	1	
28	Rocker Stop	AL514299	2	
29	Screw	AL701011	2	
30	Bolt	AL701070	1	
31	Nut	AL700122	1	



148004PM040702

ITEM NO.	DESCRIPTION.	PART NO.	QTY.	ITEM NOTE.
1	Key - ignition	AL525316	1	
2	Washer - Locking	AL514335	1	
3	Spacer	AL514336	1	
4	Switch - Ignition	AL525315	1	
5	Light Switch	AL514328	1	
6	Cap	AL514337	1	
7	Seat - Switch	AL514327	2	
8	Cable Tie	3966	2	
9	Battery	AL512073	1	
10	Clip	AL521606	2	
11	Bulb	AL514251	2	
12	Holder	AL514252	2	
13	Relay	AL521361	1	
14	Terminal	AL514319	1	
15	Circlip	AL701296	1	
16	Loom	AL521364	1	
17	Lead - Neg	AL514889	1	
18.	Lead - Pos	AL	1	
19.	Fuse 5 Amp	AL514473	1	